User Manual

PRODUCT #: CNPC	ITEM: Pedicute Pedicure Basin from Continuum		
		Continuum Footspas	

FEATURES:

The Pedicute has an adjustable, contoured footrest that supports the entire leg and positions the feet perfectly for a pedicure. A removable tub with disposable liners provides a safe and sanitary pedicure. An adjustable vibrating aqua massage with heat ensures soothing comfort and relaxation. AVAILABLE JANUARY 2010 - Pre-Orders being taken.

SPECIFICATIONS:

Dimensions: With footrest down: 17" W(43 cm) x 19" L (48 cm) x 16" H (41 cm)

Electrical: 110 VAC, 60 HZ, .75 A

Suggested Outlet: None Plumbing: None

Notes:

Warranty: 3 Year Limited
Certifications: ETL, cETL
Country of Origin: United States

Installed By: SpaEquip (if setup is included with order) or Client

www.spasalon.us Page 1 of 5

PEDICUTE[™] PORTABLE SPA

OWNERS MANUAL



pedicute BY CONTINUUM FOOTSPAS



www.spasalon.us Page 2 of 5

Product Code: CNPC

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance.
When using an electrical appliance, basic precautions should always be followed, including the following:

DANGER

To reduce the risk of electric shock:

- 1) Always unplug this appliance from the electrical outlet immediately after use and before cleaning.
- 2) Do not reach for an appliance that has fallen into water. Unplug immediately.
- 3) Do not use while in the bath or in the shower.
- 4) Do not place or store appliance where it can fall, or be pulled, into a tub or sink. Do not place or drop into water or other liquid.

WARNING

To reduce the risk of burns, electric shock, or injury:

- 1) Appliance should never be left unattended when plugged in. Unplug from outlet when not in use.
- 2) Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- 3) This appliance should not be used by, or near, children or individuals with certain disabilities.
- 4) Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Continuum Footspas.
- 5) Never operate this appliance if it has a damaged cord or plug. If it is not working or if it has been dropped, dropped in water, or damaged, contact Continuum Footspas service center for examination and repair.
- 6) Do not carry this appliance by supply cord or use cord as a handle.
- 7) Keep the cord away from heated surfaces.
- 8) Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and other debris.
- 9) Never drop or insert any object into any opening.
- 10) To disconnect, turn all controls to the OFF position, then remove plug from the outlet.
- 11) Do not use outdoors.
- 12) Do not operate where aerosol (spray) products are being used or where oxygen is administered.
- 13) Do not attempt to plug or unplug unit while feet or other body parts are in the water.
- **14)** Do not stand on or in the foot massager. Use only while seated. Place feet in massager and remove feet from massager only while in a seated position.
- 15) Never operated on a soft surface, such as a bed or couch, where air openings may be blocked.
- **16**) Use heated surface carefully as it may cause serious burns. If utilizing heating surface only, (dry massage) one <u>MUST</u> use the lowest heat setting only. Do not use over sensitive areas or in the presence of poor circulation. The unattended use of heat by children or incapacitated persons may be dangerous.
- 17) DO NOT use cracked, leaking, or otherwise damaged tub with the heating/vibrating unit.
- **18)** This appliance is designed for professional use only.

SAVE THESE INSTRUCTIONS

Product Code: CNPC

OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this appliance has a grounded plug. This plug will fit in a grounded outlet. If it does not fit, contact a qualified electrician to install a proper outlet. Do not change the plug in anyway.

CAUTIONS

The Pedicute[™] should not be used if the following cases are present: tuberculosis, benign and malignant tumors, hemorrhages, inflammations of the skin, phlebitis or thrombosis,

open or fresh wounds, bruises, broken skin or varicose veins, undetermined calf pain, or joint pain.

- Consult a physician if you have any questions regarding therapeutic use of this product.
- Consult a physician before using if clients are experiencing unexplained pain, swollen muscles, or if they have recently sustained a serious muscular injury.
- Keep away from children.
- Discontinue use of massager/heater if pain increases or swelling occurs after application.
- If clients are pregnant, please consult a physician before using.

USER/MAINTENANCE INSTRUCTIONS

The Pedicute massaging/heating platform is designed for use in a professional salon environment only with The Pedicute tub or as dry heated foot massager.

- 1) Make sure massager/heater is in OFF position.
- 2) Fill tub with warm water and place Pedicute tub on top of the massager and plug massager into wall outlet. Never plug or unplug the massager/heater while client's feet are in the water. To eliminate splashing, do not fill tub with more than 1 and 1/2 gallons of water (approximately 2.5 inches deep). Do not fill Pedicute tub to capacity.
- 3) The heat setting is desired to maintain the temperature of warm water, not to heat cold, or room temperature water.
- 4) Have clients sit in a chair and place feet in the water. Never stand in the footspa.
- 5) Turn Pedicute massager heater on by pressing the ON/OFF button and select setting on the touchpad located on the unit.
- **6)** Select one or a combination of the settings below:
 - Vibration and Heat (combination High/Low of vibration and heat)
 - Heat High/Low (heat only)
 - Vibration High/Low (vibration only)
- 7) To turn off, simply press the OFF button on the touch pad.
- 8) To select heat High/Low/Off press the heat button one, two, or three times.
- 9) To select vibration High/Low/Off press vibration button one, two, three or four times (for power massage).
- **10**) Pedicute massager/heater can also be used as a dry foot massager when used without water. Attention: use heat on low setting for dry use (without Pedicute Tub) to prevent burning.
- 11) Do not hang unit from power cord.
- **12**) To clean Pedicute massager/heater, wipe with a damp cloth (Never submerge unit in water). Do not use any strong chemical cleaners such as benzene or acetone.
- 13) Check with your state board for specific cleaning and/or sanitizing requirements.

2

www.spasalon.us Page 4 of 5

Product Code: CNPC

CONTROL FEATURES

Touchpad controls combine custom settings:

- 1) ON/OFF (OFF will turn unit off and reset previous setting).
- 2) Vibration and Heat (combinations Hi and Low heat and vibration).
- 3) Heat Only
 - a. Press heat button one time LOW. (Low heater light lit).
 - **b.** Press heat button two times HIGH. (HI heater light lit).
 - c. Press heat button three times for POWER HEAT. (Both heater lights lit).
 - **d.** Press heat button four times to turn heat OFF.

4) Massage Only

- **a.** Press vibration button one time LOW. (Low vibrating light lit).
- **b.** Press vibration button two times HIGH. (HI vibrating light lit).
- **c.** Press three times for POWER MASSAGE (both vibrating lights lit). Power Massage setting is not recommended for use with the Pedicute tub. Power Massage setting may cause water to splash.
- **d.** Press four times to turn vibration OFF.

Heater/Massager has automatic shut off (standby) feature. The massage will shut off after 35 minutes. The heat will shut off after 70 min. Simply push either the Heat or Massage button to restart the settings. **ALWAYS TURN UNIT OFF AFTER USE.**

DANGER! ELECTRIC CORDS CAN BE HAZARDOUS. Misuse Can Result in Fire or Death by Electric Shock During Use.

- Keep Children and Pets Away from Cord.
- Avoid Overheating. Uncoil Cord and Do Not Cover it with any Material.
- Do Not Drive, Drag, or Place Objects over Cord.
- Fully Insert Plug into Outlet.
- Do Not Remove, Bend or Modify Any Metal Prongs or Pins of Cord or GFCI.
- Do Not Run Through Doors Ceiling, Walls or Floors.

After Use

- Grasp Plug to Remove from Outlet.
- Always Store Indoors
- Always Unplug When Not in Use.
- Do Not Unplug by Pulling on Cord



Continuum Footspas

3

October, 2009