




# OWNER MANUAL

**SpaSalon.us**  
*wholesale*



**MODEL: ES QUEEN 450**

# SAFETY & PRECAUTION

## GROUNDING METHODS


Because this unit must be connected to a circuit with a ground-fault circuit interrupter (GFCI), DO NOT use a grounding adapter.

## GROUNDING INSTRUCTIONS

This appliance must be plugged into an outlet equipped with a ground-fault circuit interrupter. The ground-fault interrupter can be in the out-let shown in illustration A or in the circuit breaker (fuse) box. If your outlet or circuit breaker (fuse) box is not equipped with a ground-fault interrupter, you must have your electrician install one.

In the event of an electrical short-circuit, the ground-fault circuit interrupter will turn off the electrical power to the unit immediately, greatly reducing the likelihood of serious injury. This appliance is for use with a nominal 120-volt circuit and has a grounding plug that looks like the plug illustrated in the sketch. The outlet must be properly installed and grounded in compliance with all local codes and ordinances.

If it is necessary to use an extension cord, use only a three-wire extension cord that has a three-blade grounding plug and a three-slot receptacle that will accept the plug on the appliance. Replace or repair a damaged cord.




**COMPLIANCE WITH LOCAL CODES OR INSPECTIONS IS THE RESPONSIBILITY OF THE PURCHASER AND/OR INSTALLER**

## OPERATION AND USE INSTRUCTIONS

### **READ AND FOLLOW ALL INSTRUCTIONS.**

1. **IMPORTANT!** At the end of the day, **ALWAYS** turn the main power OFF!
2. **DANGER:** To reduce the risk of injury, do not permit children to use this unit unless they are closely supervised at all times.
3. **CAUTION:** This unit should not be used by persons with open wounds, cuts or sores on their feet or legs, or by persons with poor circulation, or by persons with heart conditions. If in doubt, the client should consult with his or her physician.
4. Use this unit only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer
5. Do not operate with a damaged cord or plug. If unit malfunctions or is damaged in any manner, contact an authorized service representative for examination or repair.
6. Never drop or insert any objects into any opening.
7. Do not block jets during pedicure operation.
8. Water temperature should be checked before use. Water temperature should never exceed 100 degrees Fahrenheit.
9. Never bring any electrical devices into the unit or operate electrical devices near it.
10. The unit must be connected to a supply circuit that is protected by a ground-fault circuit interrupter (GFCI).
11. Connect the unit only to a properly grounded outlet. See grounding instructions.
12. Close supervision is necessary when the unit is used by, on or near children or invalids.

## IDENTIFY YOUR FOOT-SPA




1. Glass Bowl
2. 7-colors LED light crossing the side
3. Armrest
4. Folding Manicure Tray
5. Backrest & Massage
6. Seat Cushion
7. Adjustable Footrest
8. Deluxe Hand – spray

9. Faucet
10. Jet
11. Drain Pump (optional)
12. Power / Jet Switch
13. Second remote for technician
14. Optional addition
15. Air vent



# LUX AUTO FILL SYSTEM USER MANUAL



## Preparation:

Pedicure bowl must empty and water stopper is plugged before using the Auto Fill System.



To begin simply touch the **POWER** button to turn on the AutoFill System.



Press the AUTO FILL button to begin filling the bowl. Adjust the water temperature by turning the temperature knob accordingly. Once it fills 4.2 gallon of water, it will automatically shut off and the blue **AUTO FILL** button will blink and be on lock mode. Simultaneously, the LED light and jet pump automatically turn on. After 30 seconds, the POWER button will be flashing indicating temporary lock mode.



To add more water, touch the **FILL** button. Each time the water will run for 8 seconds and automatically shut off to prevent overflow. Simply touch the FILL button again to manually stop water flow.




Touch the **JET** button to turn jet pump on and off.

**To turn off the Auto Fill System, touch and hold the POWER button for 3 seconds. The system is OFF when all button lights are off.**

**Note: The Auto Fill System will be in temporary lock mode every 30 seconds, indicated by POWER button blinking. To unlock the system, simply touch and hold the POWER button for 3 seconds.**



# IDENTIFY YOUR FOOT-SPA

## SEAT OPERATION




Armrest can be raised up/down  
Maincure tray can be folded up/down


## SPA DIMENSION



# FOOT-SPA CLEARANCE




WALL CLEARANCE



# INSTALLATIONS

## Plumbing Connections



**FAILURE TO ANCHOR THE BASE MAY RESULT IN PERSONAL INJURY OR DAMAGE TO THE UNIT. DAMAGE AS A RESULT WILL VOID THE WARRANTY.**

1. Discharge pump may be connected to an existing sink drain or floor drain. It can also pump up to 7 ft high, but this will increase the length of the drain time. The drain connection is at the rear of the unit by a 3/4" fitting.
2. Gravity drain uses a standard gravity drain. A floor drain is recommended. Connection via a P-Trap is supplied.
3. Hot and cold water supply connections are located at the rear of the unit (1/2" fittings). Please be advised that the hot and cold water supply lines are not fitted with optional back flow Preventers unless ordered at initial sale.
4. Have a qualified licensed electrician to install the wiring according to local codes. The Cleanjets are 1/10 hp, 120V, 1.2 AMP 60OHZ. A 15 amp. GFI protected circuit must be used to supply power to the unit. The roller back massage chair uses a 115V supply.
5. Spa base should be anchored securely to the floor. The base may be anchored through the opening in the back of the base wherever access is convenient for the installer.


### Electrical Service

110v, 60Hz, 15 Amp, GFCI protected grounded circuit must be use to supply power each individual pedicure spa, and the main circuit breaker must be at 25Amp. For maximum of two units per each electrical outlet



**Spa Chair Rate : 120VAC, 60HZ, 10A**



# VENTILATION

## ● Ventilation




## Typical Gravity Sink (Direct Drain) Installation






## DISCHARGE PUMP



## OPERATIONS & USE



### 1. To fill water:

The foot-spa is provided with a single hot and cold mixing valve located on the front of your spa as shown. This is a pressure balance valve that requires you to lift the handle to start the water flow and to adjust to the temperature that is desired. The clean jet motor must be completely submerged in water.

**CAUTION: DO NOT USE FOAMING, SUDSING OR MINERAL OIL BASED ADDITIVES IN THE WATER.**

### 2. To Auto Fill (Optional)

With drain open. Turn on water with mixer valve handle

Press auto fill air switch (brown & chrome)

Adjust mixer for desired water temperature

Close drain valve, bowl will fill to set water level and shut off

Mixer valve is now set open and at temperature setting for the rest of the day

\*Mixer valve must be turned off at the end of the day

### 3. To start whirlpool:

Press the jet button as shown. This will start your Jet motor. You may stop the whirlpool function at any time by pressing the button again.

4. The foot-spa is equipped with a hand held sprayer. To activate the hand shower, pull the hand shower from the receptacle and depress the thumb control on the sprayer handle. This will turn on the water. When you release pressure on the thumb control this will turn the water off.

### 5. To drain whirlpool tub:

Open the drain plug by turning the control knob as shown

### BASIC PRECAUTIONS SHOULD ALWAYS BE OBSERVED, INCLUDING THE FOLLOWING:

1. Read and follow all instructions
  2. **DANGER.** To reduce the risk of injury, do not permit children to use this unit unless they are supervised at all times
  3. Use this unit only for its intended use as described in this manual. Do not use attachments that are not Recommended by the manufacturer.
  4. Never drop or insert any object into any opening.
  5. Do not block jets during whirlpool operation.
  6. The unit must be connected to an electrical supply circuit that is protected by a ground fault circuit interrupter.
  7. The clean jet motor is magnetically driven and is insulated twice. Therefore it does not require to be bonded.
- Save these instructions