

T-201 VAPOZONE

FUNCTION:

The facial vaporizer is considered by many estheticians to be the most important electric apparatus used in the field of esthetics. The benefits of the lukewarm vapor mist are many when diffused on the skin's surface. They include the following :

1. The vapor mist softens dead surface cells so they can be sloughed off during massage or during the brushing procedure.
2. The warm humid mist aids in opening the follicles so that they can be properly cleansed.
3. The vapor penetrates deep into the follicles to soften deposits of grease, blackheads, makeup and dirt so that this debris can be removed with ease.
4. The vapor mist helps the pores to eliminate toxins.
5. The vapor mist increases blood circulation by causing the blood vessels to expand.
6. The action of the vapor improves cell metabolism.

OPERATING GUIDANCE:

1. Pour distillable water into the heat-resisting glass jar through filler spout. Do not fill it over the red-line.
2. Turn switch on then the vapor mist will diffuse from the vapor nozzle after 5-10 minutes.
3. Then turn on the switch "OZONE" for lighted up the ozone lamp, so as to spurt the IONATION vapor mist. And adjust the timer (which only T-909 and M-1 have this settle).
4. Adjust distance of steam nozzle from client in accordance with skin condition.
5. When water exhaust upto the lowest safety level the alarm will loud. And then turn off switch first before filling more water to start.
6. The appropriate vapor mist direction should be from lower chin to the whole face.

SKIN CONDITION	DISTANCE (cm)	TIME (minute)
Oily or blood circulation not well	20	15
Normal or healthy	25	10
Sensitive or dry	30	5
Skin capillaries expanding or dermatitis	30	5

CAUTION:

1. Vaporizer will turn off automatically when the water is less than 1/3 Volume.
2. Distillable water should be used in the vaporizer. The use of tap water will eventually cause malfunction of the machine, due to calcium and mineral deposits.
3. The glass jar and heating elements should be cleaned once a week by filling with a solution of distillable water and white vinegar (one cup white vinegar to one quart water), and it will be cleared overnight. The glass jar is empty and rinsed then stored until ready for use.
4. Please use the soft metal-thread brush for eliminated when the heating elements stuck with some material of lime.