


FUTURA ROLLERBALL DRYER



CONTROL PANEL



(1) START / STOP

(2) TIMER

Push to adjust time in one minute increments.

(3) TEMPERATURE

Push to adjust temperature.


(4) MODE

Options include: Perm, Treatment, Semi-Permanent Colour, Colour, Drying, Manual.

(5) FUNCTION

(6) POWER

Please turn to the OFF position when not in use.

USAGE**PROGRAMMED SETTINGS**

MODE	APPLICATION	TEMPERATURE	TIME (minutes)	FAN	HEATER	ROTATION	COOLING
PERM	For perming	3	7	off	off	on	on
TREATMENT	For conditioning treatments	3	10	off	off	on	on
SEMI-PERMANENT COLOUR	For semi-permanent colour	4	10	off	off	on	on
COLOUR	For permanent colour	5	10	off	off	on	on
DRYING	For drying natural hair	6	15	on	on	on	on
MANUAL	User sets mode	3	10	on	on	on	off

In all modes, the operator can adjust each setting according to their preferences.

OPERATING INSTRUCTIONS

1. Adjust the dryer into position (refer to the diagram in the USAGE section).
2. Turn the POWER switch to the ON position.
3. Select a MODE.
4. Adjust TEMPERATURE and TIMER if required.
5. Push START/STOP to commence treatment.
6. During operation changes can be made to the settings (but not to the MODE).
7. To interrupt operation push START/STOP.
8. At the end of the program, an electronic alarm will sound. The nape fan will activate for two minutes, after which the alarm will sound again.
9. Please turn off POWER at the end of the operation.



SAFETY & MAINTENANCE

Safety

1. DO NOT wet the accelerator. Dry your hands before touching the key pad.
2. DO NOT stop the accelerator head with your hands UNLESS it is an EMERGENCY.
3. DO NOT move or lift the unit using the head, as this may damage the unit.


Maintenance

1. Use dry and soft cloth to clean plastics, plated, and painted surfaces.
2. Use only mild neutral detergent to remove stubborn stains and dirt.



INSTALLATION & ASSEMBLY


1. Assemble the stand.



2. Insert the glide tube into dryer head.



3. Install dryer head on the stand.



WARNING – Do NOT install glide tube in stand pipe without the dryer head. The glide tube may pop out resulting in injury.

