




# OWNER MANUAL



**MODEL: LS250**

# SAFETY & PRECAUTION

Please read the instructions carefully before installing the spa chair. Carefully follow the instructions, your spa chair will give you years of beauty and service.

This product is to be connected to a branch circuit outlet protected with a Class A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). The GFCI shall be tested regularly for continued protection and correct operation. If a Class A GFCI protected outlet is not available, **DO NOT USE THIS PRODUCT!** Please contact a licensed electrician for installation of a Class A GFCI, or equivalent according to local electric codes.



**Warning**

**THIS PRODUCT IS FOR IN DOOR USE ONLY**

**DISCONNECT POWER SUPPLY CORD BEFORE SERVICING AND CLEANING**

Foot-spa must be installed by a licensed plumber and electrician in accordance with local codes. Plumbing and Electrical Installation instructions must be adhered to in order for the warranty to be in effect and to insure the utmost in safety. Chair and spa have a maximum seating capacity of **350 pounds**.

The foot-spa is not intended to be stood in or used as a step. The portable foot-spa model is movable, standing in tub or using as a step may cause severe damage to the unit as well as possible serious injury to the person.



**Warning**

If a crack occurs in the glass bowl, **DO NOT** manually handle the bowl unless the proper attire is worn. Under no circumstances must the bowl be used by your customers as you can be held accountable for any injury that may occur. We are not liable for any injury that may occur.

## **BASIC PRECAUTIONS SHOULD ALWAYS BE OBSERVED, INCLUDING THE FOLLOWING:**

1. Read and follow all instructions.
2. **DANGER.** To reduce the risk of injury, do not permit children to use this unit unless they are supervised at all times.
3. Use this unit only for its intended use as described in this manual. Do not use attachments that are not recommended by the manufacturer.
4. Never drop or insert any object into any opening.
5. Do not block jets during whirlpool operation.
6. The unit must be connected to an electrical supply circuit that is protected by a ground fault circuit interrupter.
7. The clean jet motor is magnetically driven and is insulated twice. Therefore it does not require to be bonded. Save these instructions.



**Warning**

1. Excessive water temperature is dangerous and should be checked **BEFORE** use.
2. Maximum temperature of the water should never exceed 100 degrees F.
3. Always enter and exit the Foot Spa slowly and carefully.
4. **NEVER** bring and / or operate any electrical devices into or near the Foot Spa.

# SAFETY & PRECAUTION

## GROUNDING METHODS


Because this unit must be connected to a circuit with a ground-fault circuit interrupter (GFCI), DO NOT use a grounding adapter.

## GROUNDING INSTRUCTIONS

This appliance must be plugged into an outlet equipped with a ground-fault circuit interrupter. The ground-fault interrupter can be in the out-let shown in illustration A or in the circuit breaker (fuse) box. If your outlet or circuit breaker (fuse) box is not equipped with a ground-fault interrupter, you must have your electrician install one.

In the event of an electrical short-circuit, the ground-fault circuit interrupter will turn off the electrical power to the unit immediately, greatly reducing the likelihood of serious injury. This appliance is for use with a nominal 120-volt circuit and has a grounding plug that looks like the plug illustrated in the sketch. The outlet must be properly installed and grounded in compliance with all local codes and ordinances.

If it is necessary to use an extension cord, use only a three-wire extension cord that has a three-blade grounding plug and a three-blade grounding plug and a three-slot receptacle that will accept the plug on the appliance. Replace or repair a damaged cord.



**COMPLIANCE WITH LOCAL CODES OR INSPECTIONS IS THE RESPONSIBILITY OF THE GROUNDING PIN THE PURCHASER AND/OR INSTALLER**

## OPERATION AND USE INSTRUCTIONS

### READ AND FOLLOW ALL INSTRUCTIONS


1. **IMPORTANT!** At the end of the day, ALWAYS turn the main power OFF!
2. **DANGER:** To reduce the risk of injury, do not permit children to use this unit unless they are closely supervised at all times.
3. **CAUTION:** This unit should not be used by persons with open wounds, cuts or sores on their feet or legs, or by persons with poor circulation, or heart conditions. If in doubt, the client should consult with his or her physician.
4. Use this unit only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer
5. Do not operate with a damaged cord or plug. If the unit malfunctions or is damaged in any manner, contact an authorized service representative for examination or repair.
6. Never drop or insert any objects into any opening.
7. Do not block jets during pedicure operation.
8. Water temperature should be checked before use. Water temperature should never exceed 100 degrees Fahrenheit.
9. Never bring any electrical devices into the unit or operate electrical devices near it.
10. The unit must be connected to a supply circuit that is protected by a ground-fault circuit interrupter (GFCI).
11. Connect the unit only to a properly grounded outlet. See grounding instructions.
12. Close supervision is necessary when the unit is used by, on or near children or handicapped person.

# IDENTIFY YOUR FOOT-SPA

## SEAT OPERATION

Armrest can be raised up/down

Maincure tray can be folded up/down




1. Resin Bowl
2. 7-colors LED light crossing the side
3. Armrest
4. Folding Manicure Tray
5. Backrest & Massage
6. Seat Cushion
7. Adjustable Footrest
8. Footrest

9. Faucet
10. Magnet Jet
11. Second remote for technician
12. Airvent
13. Built-in remote control




# LUX AUTO FILL SYSTEM USER MANUAL



## Preparation:

Pedicure bowl must empty and water stopper is plugged before using the Auto Fill System.



To begin simply touch the POWER button to turn on the AutoFill System.



Press the AUTO FILL button to begin filling the bowl. Adjust the water temperature by turning the temperature knob accordingly. Once it fills 4.2 gallons of water, it will automatically shut off and the blue AUTO FILL button will blink and be on lock mode. Simultaneously, the LED light and jet pump automatically turn on. After 30 seconds, the POWER button will be flashing indicating temporary lock mode.



To add more water, touch the FILL button. Each time the water will run for 8 seconds and automatically shut off to prevent overflow. Simply touch the FILL button again to manually stop water flow.




Touch the JET button to turn jet pump on and off.

---

To turn off the Auto Fill System, touch and hold the POWER button for 3 seconds. The system is OFF when all button lights are off.



*Note: The Auto Fill System will be in temporary lock mode every 30 seconds, indicated by POWER button blinking. To unlock the system, simply touch and hold the POWER button for 3 seconds.*

## IDENTIFY YOUR FOOT-SPA




**SPA DIMENSION**

# FOOT-SPA CLEARANCE



# INSTALLATIONS

## Plumbing Connections



**FAILURE TO ANCHOR THE BASE MAY RESULT IN PERSONAL INJURY OR DAMAGE TO THE UNIT.  
DAMAGE AS A RESULT WILL VOID THE WARRANTY.**

1. Discharge pump may be connected to an existing sink floor drain. It can also pump up to 7 ft high, but this will increase the length of the drain time. The drain connection is at the rear of the unit by a 3/4" fitting. Gravity drain
2. uses a standard gravity drain. A floor drain is recommended. Connection via a P-Trap is supplied. Hot and cold
3. water supply connections are located at the rear of the unit (4" fittings).  
Please be advised that the hot and cold water supply lines are not fitted with optional back flow preventers unless ordered at initial sale.
4. Have a qualified licensed electrician install the wiring according to local codes.  
The Cleanjets are 1/10 hp, 120V, 1.2 AMP 60OHZ. A 15 amp. GFI protected circuit must be used to supply power to the unit. The roller back massage chair uses a 115V supply.
5. Spa chair base should be anchored securely to the floor. The base may be anchored through the opening in the back of the base wherever access is convenient for the installer.


## Electrical Service

110v, 60Hz, 15 Amp, GFCI protected grounded circuits must be used to supply power to each individual pedicure spa, and the main circuit breaker must be at 25Amp. Maximum of two units per each electrical outlet.


**Spa Chair Rate : 120VAC, 60HZ, 10A**



# VENTILATION

## ● Ventilation




## TYPICAL Gravity Sink (Direct Drain) Installation






## DISCHARGE PUMP



# OPERATIONS & USE

## Control Panel



### 1. To fill water:

The foot-spa is provided with a single hot and cold mixing valve located on the front of your spa as shown. This is a pressure balance valve that requires you to lift the handle to start the water flow and to adjust to the temperature that is desired. The clean jet motor must be completely submerged in water.

**CAUTION: DO NOT USE FOAMING, SUDSING OR MINERAL OIL BASED ADDITIVES IN THE WATER.**

### 2. To Auto Fill (Optional)

- With drain open. Turn on water with mixer valve handle.
  - Press auto fill air switch (brown & chrome).
  - Adjust mixer for desired water temperature.
  - Close drain valve, bowl will fill to set water level and shut off.
  - Mixer valve is now set open and at temperature setting for the rest of the day.
- \*Mixer valve must be turned off at the end of the day.

### 3. To start whirlpool:

Press the jet button as shown. This will start your Jet motor. You may stop the whirlpool function at any time by pressing the button again. The jet button is not labeled in the installation.

### 4. To use water spray:

The foot-spa is equipped with a hand held sprayer. To activate the hand shower, pull the hand shower from the receptacle and depress the thumb control on the sprayer handle. This will turn on the water. When you release pressure on the thumb control this will turn the water off.

### 5. To drain whirlpool tub:

Open the drain plug by turning the control knob as shown.

## BASIC PRECAUTIONS SHOULD ALWAYS BE OBSERVED, INCLUDING THE FOLLOWING:

1. Read and follow all instructions
2. **DANGER.** To reduce the risk of injury, do not permit children to use this unit unless they are supervised at all times
3. Use this unit only for its intended use as described in this manual. Do not use attachments that are not recommended by the manufacturer.
4. Never drop or insert any object into any opening.
5. Do not block jets during whirlpool operation.
6. The unit must be connected to an electrical supply circuit that is protected by a ground fault circuit interrupter.
7. The clean jet motor is magnetically driven and is insulated twice. Therefore it does not require to be bonded. Save these instructions.

# CLEANING & MAINTENANCE

## **Please refer to the diagrams to remove jet unit components for cleaning**

We highly recommend the following cleaning regimen. You should always contact your local governing agency for their specific cleaning and disinfecting requirements and regulations for pedicure spas. For your clients safety, always use the regulations as a minimum standard for cleaning and disinfecting. Combining your states standards with the regimen listed below will provide your clients with a safe and healthy pedicure spa environment experience.

### **Routine maintenance:**

Powdered cleansers or abrasives are NOT RECOMMENDED. A clean towel or sponge, are all that are usually needed. A soft bristled brush may be used when excessive residue is present. Use a mild soap and water solution to clean the upholstery, but do not over wet. Wipe dry with a clean towel. No internal maintenance of the spa components is necessary. Remove clean jet caps and spray with disinfectant after each use. For extra protection, our recommendation is that the system be flushed daily or weekly depending on use. To flush the clean jet system fill spa with hot water to just above the jets. Add disinfectant. Run whirlpool for 15 minutes, drain and then wipe dry with clean soft cloth.

#### **NOTE:**

According to the Centers For Disease Control and Prevention (CDC), and the US Environmental Protection Agency (EPA), disinfecting occurs only when there is a reduction of pathogenic microbes at 99.999%. Sanitizing is only a reduction of 99.9%. Cleaning of whirlpool pedicure spas requires surfactant and chelating detergents that are low-foaming and have the ability to remove body oils, organic oil additives, mineral oil, skin cells, nail clippings etc that can accumulate both in the basin and the jets, which may become a fertile area for micro organisms to grow.

The use of oil based products can build up in the whirlpool system causing clogging in the jets. Adherence to the above cleaning will minimize build up. We do not recommend the use of mineral oil based products.

### **TESTING/FLUSHING FOOT SPA**

After the foot spa has been installed, fill the tub with water just above the jets. Carefully check for leaks at the drain and over flow. After checking the underside for leaks, turn on the system by pushing the whirlpool button and watch for leaks as water circulates. Let the unit run a full cycle. Open drain plug for water discharge.



# CLEANING & MAINTENANCE

## CLEANING THE MAGNET JET (Step by Step)



### Warning

- Do not place two wet ends in the same bowl when cleaning. The jets' strong magnets could cause injury (pins your fingers).
- Do not attach two wet ends to each other. Doing so will cause breakage to wet ends and will void the warranty.
- Do not run magnet jets without water. This will void your warranty.

## THREE MAGNET JET COMPONENTS



Top Plate



Magnet



Back Plate Top



Back Plate Bottom

1. Pull Magnet Jet off from the pedicure bowl.
2. Turn the Top Plate of the Magnet Jet counter-clockwise.
3. Separate the three components of the Magnet Jet: Top Plate, Magnet, Back Plate.
4. Wash each component of the Magnet Jet in a recommended or high quality solution or cleaning agent
5. Reassemble the Magnet Jet using the following directions:
  - Turn the Top Plate clockwise until you hear a "click-sound"
6. Remount the Magnet Jet onto the pedicure bowl by aligning the pegs so that the tab is at the top of the Magnet Jet.

# WARRANTY & SERVICE

Lux Spa warrants to the original purchaser that the new pedicure spa will be free from defect during the Standard Warranty Period (listed below). The shipping date and the uniquely-coded Serial Number on the back of each spa chair will justify the start of the warranty period for the product. The warranty is null and void if the pedicure spa is taken from its initial place of installation, or it is not installed in accordance with federal, state or local codes and ordinances. Also, this warranty does not apply if the pedicure spa has been subject to misapplication, improper installation or maintenance, negligence, improper cleaning or other circumstances.

## WARRANTY

1. Limited One (1) Year warranty on the Discharge/Drain Pump.
2. Limited One (1) Year warranty on the Clean Jet (Dry End).
3. Limited Three (3) Years Part-Only warranty which covers the Hydraulic System, upper massage mechanism system.
4. Lux Spa will pay standard shipping charges on all replacement part during the first 90 days of the stated Warranty Period.

*After 90 days the consumer is responsible for all labor and shipping costs occurred.*

## EXCLUSIONS

1. Damage to pump parts and/or motor parts due to obstruction in plumbing lines etc.
2. Staining, fading or discoloration of plastic surfaces due to exposure and/or the use of harmful cleaning agents or chemicals.
3. Staining, fading or discoloration caused by improper or poor water additives not related to the maintenance of proper water are not covered by this warranty.
4. Staining, fading or discoloration of the seat, armrests or footrests.
5. Freight damage, misuse, neglect, accident, natural disaster and abuse.
6. Unauthorized repairs.

## SERVICE

1. The Customer shall forward all warranty-related matters to our Customer Service Department.
2. Original Invoice must accompany all warranty claims.
3. Customers are responsible for shipping defective parts back to Lux Spa. These parts must be packaged correctly in order to protect against any further damage.
4. All parts are to be shipped by UPS Ground or USPS Service.
5. All defective parts must be shipped back to Lux spa within 30 days of receiving the new replacement parts or warranty will be void.
6. The customer must send photos and original invoice directly to Lux Spa for warranty claims that cannot be determined over the phone before any repairs can be performed.
7. Any service performed on the product without Lux Spa authorization will also void the Warranty.