Floor Drain Diagram

PEDICURE CHAIR PIPING & INSTRUMENTATION DIAGRAM, PIPE-LESS SYSTEM WITH FLOOR DRAIN NOTES: POWER SOURCE: 110V AC/ 6 AMP 60 HZ (GFI PROTECTED) CONFORMS TO UL STD 1795 AND UL STD 73 MASSAGE CHAIR WALL CERTIFIED TO CSA C 22.2 NO. 218.1 AND CAN/CSA C 22.2 NO. 68 3128265 ASME/ANSI A112 19.7M FILLER/ SHOWER **FIBERGLASS** HEAD w/ BACK FLOW AIR CONTROL PREVENTER KNOB Geni Jet only MANUAL DRAIN ACTUATOR/ OVERFLOW AIR SWITCH ANS LINER POWER SUPPLY WITH TIMER MAX. WATER LEVEL @ 4.5 GAL (15 AMP RATED) JET/LIGHT JET AIR SWITCH 12 VOLT LED LIGHT TRX 000 DRAIN PUMP AIR SWITCH DRAIN CAP 3/8" COMP. SLOPE at 1/4" per foot 1 1/2 " DISCHARGE TO S.S. VALVES P-TRAP 3/8" HOT WATER SUPPLY 12"-14' 3/8" COLD WATER SUPPLY ABOVE FINISHED FLOOR 2" to 3" DRAIN TO SEWER SYSTEM 3" HUB DRAIN WITH AIR GAP or FLOOR SINK P-TRAP



BACKFLOW PREVENTER SPECIFICATIONS (ZURN VACUUM BREAKER)

IAPMO Z7000-VB (ASSE 1014)



