

SpaSalon.us
wholesale



Embrace Pedicure Chair

IT IS IMPORTANT THAT YOU READ AND FOLLOW THESE INSTRUCTIONS.

Introduction

Thank you for purchasing Belava Embrace with “No-Plumbing”. The Embrace pedicure chair is designed for professional use in nail salons, hair salons, spas, podiatrist offices, medical spas or anywhere pedicure, manicure and facial services are offered.

The Embrace is a state-of-the-art product that embraces the use of disposable liners without having you to worry about sanitizing the footbath for each client. Simply dump the used water out at a nearby sink, toss the used disposable liner then insert a new liner and be ready for your next customer in no time. This chair is also designed to offer a comfortable setting for manicure and facial/wax services.

Please take time to thoroughly read this entire manual before use. If you have any problems or have questions regarding your pedicure chair, please contact Belava’s Technical Support Department at 1-888-708-7131 Monday through Friday 9:00AM to 5:00PM PST. After hours calls are recorded and attended to the next business day.

Important requirements

Your pedicure chair cannot operate efficiently or safely unless it is provided with adequate electrical power. The heater/massager for pedicure and the heater/vibrator for the chair’s cushion confirm to UL STD 1647.

Precautions

- Excessive water temperature is dangerous and should be checked before use.
- Maximum operating water temperature should not exceed 105° F
- Always enter and exit the pedicure chair slowly and carefully.
- This pedicure chair & nail tech stool each have a weight capacity of 350 pounds.
- With proper care, you can enjoy your Embrace pedicure chair for many years come.

Health Risk Warning

Nail technicians should advise clients to consult their physician before using the pedicure chair if there is any evidence of health issues. **If the client experiences any pain or discomfort, immediately discontinue the use of the pedicure chair.**

Embrace Pedicure Chair

— Features —



1. Headrest
2. Arm Rest
3. Relaxor Remote for Heat & Vibration
4. Pivoting Manicure Table; rotates 360° around cushion
5. Manicure Table Arch
6. Pro Foot Massager, equipped with heat & vibration
7. Adjustable Foot Rest
8. Nail Tech Stool
9. Gliders
10. Platform
11. Column
12. Embrace Chair Seat

Embrace Pedicure Chair

— Features —



Plush and extra high back fully reclines for extended service: offer eyebrow waxing, or facial treatments while keeping clients in comfortable setting.



Manicure table rotates 360 °



Manicure table pivots 360 °



Adjustable foot rest



Belava foot heater/massager
slides in and out



Turn on heater, and clients can enjoy the warmth of the water without getting cold during a pedicure.



Clients can relax their feet while you are performing manicure.

Embrace Pedicure Chair

— Specifications —

Embrace Chair measures: 48" x 34" x 48" (H x W x L)

Embrace Chair fully reclined measures: 48" x 34" x 75" (H x W x L)

Swivels up to 360° for easy in and out access

Manicure table measures: 1" x 11 ½" x 22 ½" (D x W x L); Manicure table swivels 360°

Chair Seat across: 23"

Length of Seat: 20"

Arm rest to arm rest: 29 1/2 "

Backseat height: 28"

Seat from floor to top: 44 ½ "

Chair Platform Length: 47 ¼"

Chair Platform Width: 23"

Chair Platform Height: 5"

Footrest Length: 16 ½"

Footrest height from floor to top: 22 ½"

Chair Seat Weight: 50 lbs

Platform Weight: 45 lbs

Foot rest Weight: 10 lbs

Weight Capacity: 350 lbs

Chair Weights: 105 lbs

Power Requirements: 120V DC Adaptor, 1.5 Amps, 50-60 HZ (USA).

Note: Due to continuous improvements, all specifications are subject to change without notice. All dimensions and weights are approximate.

Embrace Pedicure Chair

— Operating & Maintenance —

Care & Maintenance - With proper care, your Embrace Chair will provide years of superior performance and satisfaction. A periodic (annual minimum) inspection of chair components and fasteners should be made to ensure that the chair is structurally intact and functioning properly. Damaged and broken parts should be replaced and loose fasteners tightened.

WARNING - Failure to properly inspect and service this chair according to the maintenance instructions may lead to personal injury or product damage. Inspect chair annually for damaged or broken parts and tighten any loose fasteners. For help or additional information visit www.belava.com or call 818-708-7131.

Maintain Platform Dry - With a dry towel make sure to wipe off any spilled water on the platform.

Cleaning Cushion - The chair is upholstered in high quality automotive upholstery vinyl, which guarantees you long useful life when properly taken care of. While this vinyl is sturdy, it should be prevented from contact with sharp objects, which may leave marks or holes. Use regular cleaning solution to clean the surface; you can use auto upholstery buffing solution to restore the shine of the vinyl.

AVOID: Contact with alcohol and acetone.

Cleaning Manicure Table - To clean we recommend using a soft cloth, with any household cleaning or disinfecting solutions.

Cleaning Foot Heater/Massager - To clean we recommend using rubbing alcohol, household cleaning or disinfecting solution.

Swivel Chair - In order to safely get into or out of the Embrace Chair, simply swivel chair 90° for easy access. Once customer is seated you can swivel chair back to position.

Adjustable Foot Rest & Massager slider - To adjust massager, move massager platform rested on gliders to extend massager unit to appropriate leg comfort. To adjust footrest, simply step on foot pedal; while pressing on foot pedal you are able to adjust footrest's position by simply pushing the footrest slider in downward or upward motion to desired height. Once you have the correct height for the footrest, remove your foot off the foot pedal. This will lock the footrest in position.

Recline Chair - The handle located at the bottom left of the chair when seated. To recline simply push lever and adjust chair to needed position. The release of the lever will keep the position locked.

Operating Pro Foot Massager - Please read enclosed separate operating manual.

Operating Massage & Heat Remote for Chair - Please read page 7

Embrace Pedicure Chair

— Operating & Maintenance —

POWER

Activates Massage System

- Turn On: Press PWR.
- Turn Off: Press PWR again.
- **15 and 30 minute Timers:**
Green light = 15 minute Timer.
Hold down Power:
Amber light = 30 minute Timer.
- Unit may also be turned on by pressing either ZONE key.
To restart after Timer shuts off:
- Press PWR or either ZONE key.

HEAT

Activates Heat.

- Press LO (Amber light) to turn Low Heat on.
- Press HI (Red light) to turn High Heat on.

Works with massage or independently.

30 minute Timer

To continue after Timer shuts off, press LO or HI button again.

ZONES

(Green light indicates active Zone)

Activates Massage System

- Zone 1 once to activate massage.
Press again to deactivate.
- Zone 2 once to activate massage.
Press again to deactivate.

The location of each zone varies with individual chair styles.

INTENSITY

Controls massage motors INTENSITY during all modes. Press (+) to increase and (-) to decrease Intensity.



MASSAGE MODES

(Green light indicates active Mode)

SELECT -

Lets you choose zones for steady massage.

- Press SELECT.
- Press either or both Zones to activate.
- Press either or both Zones to cancel.

PULSE -

Massage turns On and Off to provide a pulsing action.

- Press PULSE.
- Press either or both Zones to activate.
- Press either or both Zones to cancel.

WAVE -

Massage moves up and down in a wave-like action.

- Press WAVE.
- Press both Zones to activate.
- Press any other MODE to cancel.

SPEED

Controls pulsing frequency of massage motors in PULSE mode and controls the velocity as it cycles through in WAVE.

Press (+) to increase and (-) to decrease speed.

NOTE: Constant wand lights indicates that there is active power in the wand and will dim down after 10 seconds of non-use.

SAVE THESE INSTRUCTIONS!